AC-CXWP-HDMO-BKT

HDMI WALL PLATE 70 METER EXTENDER


QUICK START GUIDE

THIS BASIC HDBASET WALL PLATE TRANSMITTER/RECEIVER KIT IS A COST EFFECTIVE HDMI EXTENSION PRODUCT FROM AVPRO EDGE'S CONFERX LINE OF PRODUCTS. ABLE TO HANDLE 4K AT 10.2 GBPS, THIS SINGLE GANG WALL PLATE TRANSMITTER FITS IN ANY STANDARD MUD RING AND WORKS WITH STANDARD CATEGORY CABLE TO DELIVER A STABLE SIGNAL LONG DISTANCES. THIS EXTENDER KIT IS ABLE TO SEND A 4K SIGNAL 40 METERS AND A 1080P SIGNAL 70 METERS USING CATGA WITH HDBASET TECHNOLOGY.

THIS QUICK START GUIDE WILL BE GOING THROUGH:

- INSTALLATION
- PRODUCT SPECIFICATIONS
- TROUBLESHOOTING





INSTALLATION


- 1. CONNECT CAT CABLE FROM THE WALL PLATE TRANSMITTER TO THE FX70 RECEIVER
- 2. POWER ON THE SYSTEM WITH THE PROVIDED POWER SUPPLY. YOU ONLY NEED TO POWER THE RECEIVER FOR BOTH UNITS TO RECEIVE POWER.
- 3. CONNECT YOUR COMPUTER TO THE WALL PLATE TRANSMITTER VIA HDMI
- 4. CONNECT YOUR DISPLAY TO THE RECEIVER VIA HDMI.



RS-232 CONFIGURATION

RS-232 CAN BE USED TO PASS CONTROL SIGNALS BI-DIRECTIONALLY TO & FROM ANY RS-232 COMPATIBLE DEVICE.

IN ORDER TO CONNECT YOUR COMPUTER TO THE EXTENDER BY RS232 YOU NEED TO MAKE YOUR OWN CABLE WITH ONE END A PHOENIX CONNECTOR AND THE OTHER END A RS-232 PORT. YOUR COMPUTER DOESN'T HAVE A RSS-232 INPUT, GET A USB CONVERTER (AS SHOWN BELOW) AND PLUG THE USB END TO ANY COMPUTER.



POWERING THE AC-CXWP-HDMO-T

THERE ARE 2 WAYS TO POWER THE UNIT:

- 1. USE A HDBASET RECEIVER THAT PROVIDES UP STREAM POWER. THIS KIT COMES WITH THE A RECEIVER WITH THE ABILITY TO DO SO (AC-EX70-UHD-BKT)
- 2. IF YOU WILL BE USING THE WALL PLATE TRANSMITTER DIRECTLY INTO A NON POE PROVIDER (AVR, PROJECTOR, DISPLAY, OR OTHER HDBASET RECEIVER), YOU CAN POWER IT USING A 5V MINI USB TYPE POWER SUPPLY.

TROUBLESHOOTING

VERIFY POWER: VERIFY CONNECTIONS - CHECK THAT ALL CABLES ARE PROPERLY CONNECTED

IR ISSUES: VERIFY CORRECT CONNECTIONS - VISIBLY FLASHING EMITTERS MAY NOT FUNCTION PROPERLY, TRY THE IR CABLES THAT COME IN THE BOX IF YOU ARE EXPERIENCING ISSUES



HAVE A QUESTION OR NEED ASSISTANCE? DON'T HESITATE TO CONTACT US!

SUPPORT: +1 605-274-6055

USA TOLL FREE: 877-886-5112

EMAIL: SUPPORT@AVPROEDGE.COM

